



INSTRUCTIONS FOR USING THE HOT TUB

Dear Guest, please read these instructions carefully before using the hot tub – you are responsible for any damage caused to the tub or the stove.

WARNING: Never light the stove when the tub is empty or only partially filled!

Heating a partially filled tub will always cause the stove to melt. Always check the water level before lighting the stove. The tub must be filled at least 10 cm above the upper connection pipes of the stove before lighting a fire. The required fill level depends on how many people will use the tub. Please check the maximum number of users from the property owner or caretaker. If the maximum capacity is exceeded, too much water may spill out of the tub, which can damage the stove.

Also note that you must not drain the tub before the fire and embers in the stove are completely extinguished and the stove is no longer hot. Draining the tub too early will also damage the stove.

The hot tub cover must always be kept on when the tub is not in use. Please check with the owner for any additional instructions regarding use of the cover.

LIGHT THE TUB SAFELY: Only use appropriate fire-starting materials, such as firelighters. Do not use any unsuitable or hazardous substances.

HEAT THE WATER TO A SAFE TEMPERATURE: The recommended water temperature is **35–37°C**. Higher temperatures can feel uncomfortably hot. **Never heat the water above 40°C** for safety and comfort.

ALLOW ENOUGH HEATING TIME: Heating the tub usually takes **3–4 hours**. Heating time depends on factors such as the cover being used, the dryness of firewood, and the temperature of added water. Before getting into the tub, **mix the water thoroughly** so the colder water from the bottom blends with the warmer water on top.

WASH BEFORE ENTERING: The water stays cleaner and the hot tub remains more pleasant when you wash before getting in. For example, rinse off sweat after coming from the sauna. **Be careful with drinks** to avoid unnecessary spills that can dirty the water.



IMPORTANT: Do not use glass bottles or drinking glasses in or around the hot tub. Broken glass is extremely dangerous in the water and surrounding area, and glass shards can be nearly impossible to spot. Please use only plastic or metal drinkware.

BE CAREFUL WHEN ENTERING AND EXITING: Especially in winter, water splashing from the tub can freeze and make the surroundings slippery. Take extra care, especially with children.

EMPTY THE TUB ONLY AFTER THE STOVE HAS COMPLETELY COOLED: The stove must **never** be hot when the tub is empty – otherwise the stove will melt. During winter, the tub must be emptied immediately after use if it will not be heated again the next day. If there is a break between uses, ensure the water stays at least **20°C** to prevent freezing.

Only drain the tub when the water is warm, as cold water can freeze in the drainpipe. **Never drain the tub before the fire and embers are fully extinguished.** Drain the water only to the designated location approved by the owner.

Check with the owner/caretaker for the hot tub cleaning routine and the procedure for removing ashes from the heater (typically the ashes must be emptied after every heating session, making sure they are completely cooled beforehand).

IMPORTANT! The guest must heat and use the hot tub according to these instructions. The guest is responsible for any damage caused to the stove, tub, or cover. For example, replacing a melted stove can cost over €2000, depending on delivery and installation costs.

I have read and understood the instructions for using the hot tub and acknowledge that I am responsible for any damage caused.

Location and date:

Signature and name:
